

Quick Reference

Follow these steps to get started copying, playing and recording VHS tapes!



Play Play a Tape


1. Insert Tape in Deck 1 or Deck 2
2. Press *PLAY*
(Most rented movies will play automatically when inserted!)

Record Record a TV Show

1. Insert Tape in Deck 1 or Deck 2
(The tape must have a record safety tab!)
2. Select Channel to Record
(On the VCR! The TV should be set to channel 3!)
3. Press *REC*

Copy Copy a Tape

1. Insert Tape in Deck 1
(The one you want to copy!)
2. Insert Tape in Deck 2
(The blank tape!)
3. Press *COPY TAPE*



Questions?



DO NOT RETURN THIS PRODUCT TO THE STORE!

Our Award-Winning Customer Service Professionals are Ready to Help!

E-Mail Us!

For a Prompt Reply

customersupport@sonicblue.com

Check Our Website!

For the Latest Support Information

www.sonicblue.com

Or Call Us!

For Fast, Friendly Service

[1-800-736-7679](tel:1-800-736-7679)